

样式 Photo	图纸 Contour	样式 Photo	图纸 Contour	样式 Photo	图纸 Contour
GXB2-PE16F		GXB2-PE16A		GXB2-PE22A	
GXB2-PE22W		GXB2-PE30C		GXB2-PE22B	
GXB2-PE22BH		GXB2-PE22F		GXB2-PE22F	
GXB2-PE22FH		GXB2-PE22CF		GXB2-PE22CHF	
GXB2-PB16		GXB2-PB22		GXB2-PB30	
GXB2-EH2201		GXB2-EH2208		GXB2-EH2204	
GXB2-EH2206		GXB2-EH2225		GXB2-EH2230	

样式 Photo	图纸 Contour	样式 Photo	图纸 Contour	样式 Photo	图纸 Contour
GXB2-ER25 (AD22-ER25)		GXB2-ER30 (AD22-ER30)		GXB2-ZB16F	
GXB2-EB22P		GXB2-EB40P		GXB2-ZB16CF	
GXB2-ER40		GXB2-ER60		GXB2-ER90	
GXB2-EC2		GXB2-EC3		GXB2-EC4	
GXB2-EB30		GXB2-EB40		GXB2-EB60	
型号(Type) : GXB2-ER66		型号(Type) : GXB2-EC5-1		型号(Type) : GXB2-EC5	

按钮附件
parts of push button series

按钮附件
parts of push button series