



描述 Description & 颜色 Color			描述 Description & 颜色 Color						
 Flush Button	LA115-1-BN Momentary 平钮头部 (自复)	LA115-1-T Maintained 平钮头部 (自锁)	 Short Handle Selector	LA115-1-XS Momentary 2&3-Positon 两/三档自复旋钮	LA115-1-X Maintained 2&3-Positon 两/三档自锁旋钮				
 Flush Button Illuminated	LA115-1-D Momentary 平钮头部 (带灯自复)	LA115-1-TD Maintained 平钮头部 (带灯自锁)	 Short Handle Selector Illuminated	LA115-1-XS Momentary 2&3-Positon 两/三档自复旋钮 (带灯型)	LA115-1-X Maintained 2&3-Positon 两/三档自锁旋钮 (带灯型)				
 Extended Button	LA115-1-H Momentary 凸钮头部 (自复)	LA115-1-HT Maintained 凸钮头部 (自锁)	 Selector Long Handle	LA115-1-CX Momentary 2&3-Positon 两/三档长柄旋钮 (自锁型)	LA115-1-CX/FU Momentary 2&3-Positon 两/三档长柄旋钮 (自复型)				
 Extended Button Illuminated	LA115-1-HD Momentary 凸钮头部 (带灯自复)	LA115-1-HTD Maintained 凸钮头部 (带灯自锁)	 Selector Long Handle Illuminated	LA115-1-CXD Momentary 2&3-Positon 两/三档长柄旋钮 (带灯自锁型)	LA115-1-CXD/FU Momentary 2&3-Positon 两/三档长柄旋钮 (带灯自复型)				
 Mushroom Button	LA115-1-M Momentary 蘑菇钮头部 (自复)	LA115-1-MT Maintained 蘑菇钮头部 (自锁)	 双键平钮 Double (Flush Botton)	LA115-1-R <table><tr><td>ON</td><td>OFF</td></tr><tr><td>START</td><td>STOP</td></tr></table>		ON	OFF	START	STOP
ON	OFF								
START	STOP								
 Mushroom Button Illuminated	LA115-1-MD Momentary 蘑菇钮头部 (带灯自复)	LA115-1-MTD Maintained 蘑菇钮头部 (带灯自锁)	 双键带灯平钮 Double (Flush Botton)Illuminated	LA115-1-RD <table><tr><td>ON</td><td>OFF</td></tr><tr><td>START</td><td>STOP</td></tr></table>		ON	OFF	START	STOP
ON	OFF								
START	STOP								
 Emergency Stop Pushbutton	LA115-1-ZS Twist Release Non-illuminated 急停头部 旋转释放 (不带灯型)		 key-operated Selector	LA115-1-Y/FU Momentary 2/3-Positon 两/三档自复型	LA115-1-YS Maintained 2/3-Positon 两/三档自锁型				
 Flush Button	LA115-2-BN Momentary 平钮头部 (自复)	LA115-2-T Maintained 平钮头部 (自锁)	 Short Handle Selector	LA115-2-XS/FU Momentary 2&3-Positon 两/三档自复旋钮	LA115-2-X Maintained 2&3-Positon 两/三档自锁旋钮				
 Flush Button Illuminated	LA115-2-D Momentary 平钮头部 (带灯自复)	LA115-2-TD Maintained 平钮头部 (带灯自锁)	 Short Handle Selector Illuminated	LA115-2-XSD/FU Momentary 2&3-Positon 两/三档自复旋钮 (带灯型)	LA115-2-XD Maintained 2&3-Positon 两/三档自锁旋钮 (带灯型)				

描述 Description & 颜色 Color			描述 Description & 颜色 Color		
	LA115-2-H Momentary 凸钮头部 (自复)	LA115-2-HT Maintained 凸钮头部 (自锁)		LA115-2-CX Maintained 2&3-Positon 两/三档长柄旋钮 (自锁型)	LA115-2-CX/FU Momentary 2&3-Positon 两/三档长柄旋钮 (自复型)
Extended Button			Selector Long Handle		
	LA115-2-HD Momentary 凸钮头部 (带灯自复)	LA115-2-HTD Maintained 凸钮头部 (带灯自锁)		LA115-2-CXD Maintained 2&3-Positon 两/三档长柄旋钮 (带灯自锁型)	LA115-2-CXD/FU Momentary 2&3-Positon 两/三档长柄旋钮 (带灯自复型)
Extended Button Illuminated			Selector Long Handle Illuminated		
	LA115-2-M Momentary 蘑菇钮头部 (自复)	LA115-2-MT Maintained 蘑菇钮头部 (自锁)		LA115-2-R	
Mushroom Button			双键平钮 Double (Flush Botton)		
	LA115-2-MD Momentary 蘑菇钮头部 (带灯自复)	LA115-2-MTD Maintained 蘑菇钮头部 (带灯自锁)		LA115-2-RD	
Mushroom Button Illuminated			双键带灯平钮 Double (Flush Botton)Illuminated		
	LA115-2-ZS Twist Release Non-illuminated 急停头部 旋转释放 (不带灯型)			LA115-2-Y/FU Momentary 2/3-Positon 两/三档自复型	LA115-1-YS Maintained 2/3-Positon 两/三档自锁型
Emergency Stop Pushbutton			key-operated Selector		
样式 Photo	描述 Description	样式 Photo	描述 Description	样式 Photo	描述 Description
	NO -3 -4 LA115-A-10 常开触点模块 Contact block		NO -3 -4 NC -1 -2 LA115-B-11 Contact block 1常开1常闭触点模块(B型)		1NC LA115-A-Z01 1NO LA115-A-Z10 1NO 1NC LA115-A-Z11
	NC -1 -2 LA115-A-01 常闭触点模块 Contact block		R--红色 B--蓝色 G--绿色 W--白色 Y--黄色 一体式LED灯座(B型) Lamp block with LED		1NC LA115-A-Z01 1NO LA115-A-Z10 1NO 1NC LA115-A-Z11
	X1 X2 LA115-A-D1 BA9S 灯座 BA9S base		LA115-A-Z A型中座 (可接三副模块) For three blocks		R--红色 (red) G--绿色 (green) Y--黄色 (yellow) B--蓝色 (blue) W--白色 (white)
	X1 X2 LA115-A-D2 一体式LED灯座 Integrated lamp block		LA115-B-Z B型中座 (可接一副模块) For one block		LA115-22FF 紧固圈(防松) Fastening ring (anti loosening)

LA115-A/B按钮系列
LA115-A/B push button series

LA115-A/B按钮系列
LA115-A/B push button series